

Toyota Update Description

- 1、 Software request: must be V090803 (2009-8-3) or higher.
- 2、 Hardware request: Must do hardware upgrade before using the new function.

Software:

Download and install 090803 version or higher.

Hardware: upgrade stpes

AD-1 Hardware upgrade:




Note: Pls make sure the computer installed with AD-1 software with internet.

- 1、 Connect the AD-1 main unit with Computer (The bigger USB head connect with PC, the smaller usb head connector to the AD-1 main unit)
- 2、 After finished step 1, then go to the AD-1 software page: And click the button “HWUPGRADE”.::




- 3、 And then:



4、 Select BEGIN to start the upgrade:



5、 After HWUPGRADE success, click RETURN.



New functions after update

TOYOYTA (CAN-BUS) Menu

UPDATE CAR TYPE YEAR: 2009

		CURRENT DTC	HISTORY DTC	ERASE DTC	Pending DTC	DATA LIST
POWER	ENGINE	√	√	√	√	√
	ECT	√	√	√	√	√
	RAdAR Cruise	√	√	√		√
	Hybrid Control	√	√	√		√
	HV Battery	√		√		√
	Stop and go	√	√	√		√
	E-ACM	√	√	√		√
CHASSIS	Rear Stabilizer	√	√	√		√
	Transmission Control	√		√		√
	Air Suspension	√	√	√		√
	Lane Keeping Assist	√	√	√		√
	ABS/VSC/TRC	√		√		√
	EMPS	√	√	√		√
	Four Wheel Drive	√		√		√
	Tire Pressure Monitor	√	√	√		√
	AHC	√	√	√		√
	Electric parking Brake	√		√		√
	Intelligent Parking Assist	√	√			√
	Front Stabilizer	√	√	√		√
	BODY	Theft Deterrent	√		√	
Main Body		√	√	√		√
Body NO.4		√		√		√
Body NO.5						√
Accessory Gateway		√	√	√		√

BODY

ECM Gateway	√	√	√		√
ECB Gateway	√	√	√		√
WIL Gateway	√	√	√		√
PM1 Gateway	√	√	√		√
PM2 Gateway	√	√	√		
Front Right Door					√
Front Left Door					√
Rear Left Door	√	√	√		√
Rear Right Door	√	√	√		√
Front left A/C	√				√
Front Right A/C	√				√
Passenger Seat					√
Rear Left Seat	√		√		√
Rear Right Seat	√		√		
D-SEAT SW	√	√	√		√
Center Console Switch					√
Rear Console switch	√	√	√		√
Steering Pad Switch					√
Combination switch					√
Active Headrest R	√	√	√		√
Active Headrest L	√	√	√		√
Electric Power Control	√	√	√		√
Mirror					√
Navigation System	√	√			√
Power Source Control	√	√	√		√
Driver Seat					√
Rain sensor	√	√	√		√
Tilt&Telescopic	√	√	√		√
AFS	√	√	√		√
Clearance Sonar	√	√	√		√
Master Sonar	√		√		√
Rear Left Seat A/C	√				√

BODY

Rear Right Seat A/C	√				√
Rear Left Door motor	√	√	√		√
Rear Right Door motor	√	√	√		√
D Door Motor	√	√	√		√
P Door Motor	√	√	√		√
Back Door	√		√		√
Passenger Door					√
Enter & Start	√	√	√		√
Sliding Roof	√	√	√		√
HV Gateway	√	√	√		√
Gateway	√	√	√		
Charging Control	√	√	√		
Combination Meter	√	√	√		√
Pre-Crash	√	√	√		√
Pre-Crash2	√	√	√		√
SRS Airbag	√	√	√		√
Air Conditioner	√	√	√		√